

# A 256-TES array for the detection of **CMB B-mode polarisation**





C. Perbost<sup>1</sup>, B. Bélier<sup>2</sup>, S. Marnieros<sup>3</sup>, M. Piat<sup>1</sup>, D. Prêle<sup>1</sup>, F. Voisin<sup>1</sup>, T. Decourcelle<sup>1</sup>

<sup>1</sup>Laboratoire AstroParticule et Cosmologie (APC), Paris, France; <sup>2</sup>Institut d'Électronique Fondamentale (IEF), Orsay, France; <sup>3</sup>Centre de Sciences Nucléaires et de Sciences de la Matière (CSNSM), Orsay, France;


Contact: camille.perbost@apc.univ-paris7.fr

#### **Context**

The Cosmic Microwave Background (CMB), very first light emitted by the Universe, is a fundamental source of information for modern cosmology. Partly polarised, this radiation should display imprints left by gravitational waves during the early Universe: B-modes. As it would constrain inflation models, millimetre-wave detection of Bmodes is therefore one of the most challenging issue of present cosmology. In order to detect this very faint signal, next generation of CMB instruments needs large detector arrays to ensure high sensitivity in addition to a good control of systematic effects. We present here the manufacturing process and first cryogenic results of a ¼ of the QUBIC instrument's focal plane which targets B-modes.

# The TES, a superconducting bolometer


A bolometer is a thermal detector. It consists first of a grid that absorbs incoming waves. This absorption causes an increase of temperature measured by a sensor whose resistance is temperaturedependant. The information on the incoming wave is contained in the resistance fluctuations of the sensor. The bolometer is thermally insulated from its environment by legs.




A Transition Edge Sensor (TES) is a bolometer with a superconducting thermometer. It is polarised so as to operate on its transition, where small temperature fluctuations lead to large resistance changes.

## Manufacturing of a 256-TES array


TES arrays are crafted following several microfabrication steps performed in a clean room. First, the Si<sub>3</sub>N<sub>4</sub> membrane, the NbSi thermometers and the Al wires are fully evaporated in layers on top of a SOI (Silicon on Insulator) substrate.



The top two layers (Al and NbSi) are then respectively etched to the shape of wires and thermometers. After that step, room temperature tests can be performed to control the routing. The TiV absorbing grid is then deposited on the top by lift-off. ☐ Si



The back layers are removed to release the membrane, then the legs are excavated from the Si<sub>3</sub>N<sub>4</sub>. The bolometers are at the end of Si the process completely in suspension.



## NbSi thermometers with tunable T<sub>c</sub>

A specificity of our design is that our sensors are made of NbSi, an amorphous material that can exhibit either an insulating, a metallic or a superconducting behaviour depending mostly on the percentage of **Nb**. The critical temperature can be inferred from that percentage then reduced to fit our needs by annealing the sample.





Figure : Critical temperature of NbSi sensors as a function of Nb percentage before annealing. Two different methods are compared : coevaporation (dotted line) and co-sputtering (dashed line) technique.


### Control tests



In order to control the yield of an array, each of the 256 TESs is electrically and individually tested at room temperature before cryogenic integration. This operation doesn't provide any information on the bolometers' performance at cryogenic temperature but is essential to make sure that at least 90% of the TESs is correctly connected at the end of the production line.


### Read-out chain

For cryogenic tests, the TESs are voltage biased and cooled down to ~ 300 mK. They are then coupled to a 1:128 time domain multiplexing electronics based on SQUIDs with an additional SiGe integrated circuit which provides a second multiplexing stage.



#### First results at cryogenic temperature

A 256-TES array has a critical temperature (T<sub>c</sub>) around **420mK** and is regulated in a dilution fridge at a temperature below T<sub>c</sub>. Being voltage-biased, the TESs work at a stable and controlled temperature due to an electrothermal feedback: any variation of temperature of thermal origin will induce an opposite electrical temperature



When regulated at  $T_{bath} < T_c$ , a TES can be forced into its normal state by maintaining high bias voltage (right part of the curves). While decreasing the voltage, the TES slowly transits to its superconducting state and the electrothermal feedback starts (minimum of the I-V curves). Thus the TES works at constant power (plateau on the P-V curves). The figure also shows good homogeneity between the pixels.